

INSTRUCTIONS ON HOW TO MAKE A 7' WIDE CONVERTIBLE
EZ up MESH PANEL

1. Using needle nose pliers, pull out the 5' (actually it's 57") aluminum flat bar from the top and bottom edges on the side where the rear door will be.
2. Using a hacksaw, cut through both flat bars 34" from the end. This should leave you with two 34" pieces and two 23" pieces.
3. Put the 23" pieces back in the top and bottom edges first; then, put the 34" pieces in both edges.
4. Then, follow directions on Convertible Mesh Panel Wall for 7' – wide walls.