

INSTRUCTIONS ON HOW TO MAKE A 7' CONVERTIBLE MESH PANEL

1. Using needle nose pliers, pull out the 5' (actually it's 57 3/4") aluminum flat bar from the top and bottom edges on the side where the rear door will be.
2. Using a hacksaw, cut through both flat bars 35 3/4" from the end. This should leave you with two 35 3/4" pieces and two 22" pieces.
3. Put the 22" pieces back in the top and bottom edges first; then, put the 35 3/4" pieces in both edges.
4. Then, follow directions on Convertible Mesh Panel Wall for 7' – wide walls.