

Rear Door Frame Assembly Instructions

To Add Rear Door Frame to TrimLine canopy

Important: Review these instructions completely **before assembling your canopy.** Door frame assembly is put into place as the canopy is being set up. Refer to picture on page 2.

Parts List:

- (1) Canopy Leg Top – 58 ¼" – coded black
- (1) Canopy Leg Bottom – 24" – coded black
- (1) Leg Adjuster sleeve
- (1) Canopy Foot
- (1) 22 ½" female pole (for 7 ft. StaBar pole)
- (2) StaBar Ell joints
- (1) Door Ell joint



Assembly:

1. While assembling canopy frame, slide Door Ell joint onto rear upper horizontal pole (on Archtop this is the purple coded pole, on TrimLine it is either purple or no-color pole depending on how you face the roof).
2. When assembling legs slide StaBar Ell joint onto the right rear leg, StaBar 3-way joint onto the left rear leg (as seen from in front of booth looking in - see picture on page 2).
3. Assemble the fifth leg with StaBar Ell joint in place.
4. When canopy is erect on 4 legs, slide Door Ell joint to approximately 3-ft from the right rear corner and insert the fifth leg into it.
5. Assemble StaBar poles so that you have 2 at 10-ft and 1 at 7-ft (for 7 ft. stabar, use a standard male no-color pole and the 22 1/2" female pole). Attach StaBar poles, beginning with the rear 7 ft. pole, sliding the Door Ell joint into it's final position so that the fifth leg stands plumb.
6. See Picture on page 2.

