

Rear Door Frame Assembly Instructions

To Add Rear Door Frame to TrimLine canopy

Important: Review these instructions completely **before assembling your canopy.** Door frame assembly is put into place as the canopy is being set up. Refer to picture on page 2.

Parts List:

- (1) Telescoping Leg Top – 50 ¼"
- (1) Telescoping Leg Bottom – 47"
- (1) Canopy Foot
- (1) 22 ½" female pole (for 7 ft. StaBar pole)
- (2) StaBar Ell joints
- (1) Door Ell joint



Assembly:

1. While assembling your canopy frame, slide a Door Ell joint onto the rear upper horizontal pole of your TrimLine.
2. Slide Stabar joints onto the corner leg bottoms, with a StaBar Ell on the right rear leg, and a StaBar 3-way on the left rear leg (as seen from in front of booth looking in - see picture on page 2). Or, reverse the corner where you want the rear door.
3. Slide a Stabar Ell onto your fifth leg.
4. When canopy is erect on 4 legs, slide the Door Ell joint to approximately 3-ft from the right rear corner and insert the fifth leg into it.
5. Assemble StaBar poles so that you have 2 at 10-ft and 1 at 7-ft (for 7 ft. stabar, use a standard male no-color pole and the 22 1/2" female pole). Attach StaBar poles, beginning with the rear 7 ft. pole, adjusting the Door Ell joint into it's final position so that the fifth leg stands plumb and square.
6. See Picture on page 2.

