

## French Wall Instructions for 7 ft. Mesh Panel


### PARTS LIST:

- |                                       |                                   |
|---------------------------------------|-----------------------------------|
| (2) Standard male No-color Pole – 61" | (1) Red-coded female Pole – 54 ¼" |
| (1) 22 ½" female pole section         | (2) 58 ¼" leg top – coded black   |
| (2) 24" leg bottom - coded black      | (1) Offset Leg Joint              |
| (1) Long Tee Joint                    | (1) Door Ell Joint                |
| (2) StaBar Ell Joint                  | (2) Canopy Foot                   |
| (2) Leg Adjusters                     |                                   |

### ASSEMBLY:



1. While assembling the roof frame (for a canopy) or the upper horizontal poles (for an indoor booth), slide the offset leg joint and the long Tee joint onto the upper horizontal poles opposite each other. See diagram below.



2. After canopy or indoor booth frame is completely assembled, insert the red-coded end of the assembled light pole (1 no color male and 1 red coded female with door ell) as far as possible into the long Tee Joint.
3. Slide the pole the other direction into the opposite offset leg Joint until it clicks into place.
4. Assemble two legs as per canopy or booth frame instructions, with a StaBar ell on each leg bottom. Slide one leg into the down barrel of the offset leg joint, and one into the door ell.
5. Assemble a 7' StaBar pole using one no color male and one 22 ½" female pole section. Slide the 7' StaBar pole into each of the two StaBar ells on the leg bottoms.
6. Attach 7' Mesh Panel