

E-Z up Rear Door Frame Assembly Instructions

To Add Rear Door Frame to E-Z up or other pop-up Canopy

Parts List:

- | | |
|---|--------------------------------------|
| (1) Telescoping Leg Top – 50 ¼" | (1) StaBar EII Joint |
| (1) Telescoping Leg Bottom – 36 ½" | (1) EZ StaBar ELL |
| (1) Canopy Foot | (1) Door EII joint |
| (1) 22 ½" female pole (for 7 ft. StaBar pole) | (6) Thumbscrews (thread onto joints) |



Assembly:

1. While assembling Upper Stabilizer Bars (as per upper StaBar instructions), slide Door EII joint onto rear upper stabar pole.
2. Assemble the fifth leg with StaBar EII joint in place (white arrow up). See Page 2.
3. When upper StaBar poles are in place, slide Door EII joint to approximately 3-ft from the right rear corner and insert the fifth leg into it.
4. Assemble lower StaBar poles so that you have (2) 10-ft poles and 1 7-ft pole. (for 7 ft. pole, use a standard male no-color pole and the 22 1/2" female pole).

- Attach lower StaBar poles as per lower StaBar instructions. Beginning with the rear 7 ft. pole, slide the Door Ell joint into it's final position so that the fifth leg stands plumb. Snap the 7 ft. pole into the StaBar 3 way on one side, and the StaBar ell on the fifth leg on the other side. Complete the installation of the lower StaBar poles as per instructions.

Instructions for Using Your Telescoping Legs

Your telescoping legs will arrive to you in the “collapsed” position with the inner “bottom” section completely inside the outer “top” section – see photo above.

To begin, grasp the top section firmly and shake downwards to slide the bottom section out slightly.

- Note that there is a hole near the top of the outer section well above the long row of holes. Pull the inner section out about 6 inches and rotate until the snap button at the top of the inner section finds that hole and clicks into place.
- If you are using your legs for a Trimline canopy or a Mesh Panel Booth Frame you may slide your StaBar Ell or StaBar 3 way fittings onto the leg bottom before attaching the foot.
- Slide a foot onto each leg and rotate until the snap button in the leg clicks into the snap button hole in the foot.
- The telescoping leg is designed so that in the “collapsed” position you may keep the foot and/or the StaBar fittings on the leg when transporting them.
- To extend the leg for use it's handy to use your toe to hold the foot plate down while lifting the outer section. Lift up until a snap button pops out from the inner section.
- You may then rest the upper section on this snap button while you rotate the inner section until another snap button clicks into the topmost hole in the long row of holes. This is the extended position. From there you may simply extend the leg one hole at a time to reach the desired height or to account for uneven terrain in outdoor uses.
- To collapse the leg simultaneously push in the “rest” snap button and the snap button in the long row of holes, and slightly rotate the inner section so the snap button does not catch in each hole on the way down.

