

## FRENCH WALL FRAME FOR CANOPY



### INSTRUCTIONS FOR ASSEMBLY

NOTE: Review these instructions **before** assembling your canopy.

#### Parts List:


- |                  |                          |
|------------------|--------------------------|
| (1) Ell Joint    | (1) Offset Leg Top Joint |
| (2) Canopy Feet  | (2) StaBar Ell Joints    |
| (13) Thumbscrews | (2) Leg Adjuster Sleeves |

- (2) 45 1/2" Upper and Lower StaBar pole (coded red)  
(2) 58 1/4" Leg Tops (coded black)  
(2) 23" Leg Bottoms (coded blue)



The French Wall Mesh Panel may be set up at almost any position from the front of your booth to the back. More than one French Wall Mesh Panel may be used to increase your display space. The single French Wall Mesh Panel is often set 2- or 3-ft from the rear of the booth to create a closet in which to store inventory, keep equipment, or handle sales.

1. While assembling your canopy, slide the Offset Leg Top (white arrow pointing down) onto the upper horizontal pole against which the French Wall Mesh Panel will stand, at a distance in front of the rear wall which you must determine.



## Door Ell

## Offset Leg Joint

2. Complete the assembly of your canopy.
  3. Attach all 10-ft (and 8-ft) wide MeshPanels (and their Pro Gallery Covers if applicable). Refer to your MeshPanel setup instructions. This is best done BEFORE assembling the French Wall framework.
  4. Assemble two legs, as per sidebar diagram. Slide StaBar Ell joints - arrow facing down - onto the legs and complete the assembly by inserting a canopy foot onto the bottom of each leg. Insert one of the legs into the Offset Leg Joint.
  5. Slide the Ell Joint onto a Red-coded pole, and then insert the other end of the pole into the open barrel of the offset leg top joint.
  6. Insert the second leg assembly into the open barrel of the Ell joint.
- Note: If small adjustments in the height of the French Wall legs are needed, the snap buttons in the leg adjuster may be pushed in, allowing the leg poles to move into proper alignment. After this is done, use the thumbscrew on the adjuster to secure the leg pole in place.
7. Insert the other Red-coded pole into the open barrel of one of the remaining StaBar Ells, then into the other StaBar Ell.
  8. Attach 4-ft MeshPanel using same method as described in MeshPanel instructions.

