

INSTRUCTIONS FOR ASSEMBLY - FRENCH WALL FRAME FOR EZ UP CANOPY

Parts List:

- (1) Ell Joint
- (2) Feet
- (2) 45 ½" – or – 33 ½" horizontal poles (coded red)
- (2) Telescoping Legs
- (13) Thumbscrews
- (1) Offset Leg Joint
- (2) StaBar Ell Joints





The French Wall Mesh Panel for the EZ up canopy requires the use of an upper stabilizer bar on the EZ up. Please refer to your EZ up stabilizer bar instructions in addition to these instructions. Your French Wall Mesh Panel may be set up at almost any position from the front of your booth to the back. More than one French Wall Mesh Panel may be used to increase your display space. The single French Wall Mesh Panel is often set 2 or 3 ft. from the rear of the booth to create a closet in which to store inventory, keep equipment, or handle sales.

1. While assembling your upper stabilizer bar (refer to StaBar instructions), slide the Offset Leg joint onto the upper horizontal pole against which the French Wall Mesh Panel will stand, at a distance in front of the rear wall which you must determine. See picture.
2. Complete the assembly of your canopy as usual.
3. Attach all 10-ft wide MeshPanels (and their Pro Gallery Covers if applicable). Refer to your MeshPanel setup instructions. This is best done BEFORE assembling the French Wall framework.
4. Using two telescoping legs, Slide StaBar Ell joints - arrow facing down - onto the legs and insert a foot onto the bottom of each leg. Insert one of the legs into the Offset Leg Joint.
5. Slide the Ell Joint onto a Red-coded pole, and then insert the other end of the pole into the open barrel of the offset leg top joint.
6. Insert the second leg assembly into the open barrel of the Ell joint.
7. Insert the other Red-coded pole into the open barrel of one of the remaining StaBar Ells, then into the other StaBar Ell.
8. Attach 4-ft MeshPanel using same method as described in MeshPanel instructions.



9. See page 2 for illustration.



Note: Shown with optional rear door frame