

## ZIGZAG MESH PANEL FRAME FOR OUTDOOR CANOPY

### INSTRUCTIONS FOR ASSEMBLY

#### **Parts List:**

(2) Indoor Ell                      (2) Indoor 3 way                      (2) StaBar Ell  
(2) StaBar 3 Way                      (4) Feet                      (33) Thumbscrews  
(6) 9" Black Ball Bungees (for bundling poles)

(4) 50 1/4" Telescoping Leg Tops  
(4) 47" Telescoping Leg Bottom Poles  
(6) 33 1/2" Upper and Lower StaBar poles (coded red) **OR**  
(6) 45" Upper and Lower StaBar poles (coded red) for 4' ZigZag ) **OR**  
(6) 56 1/2" Upper and Lower StaBar poles (coded red) for 5' ZigZag  
for Oversize ZigZag frame

(1) Carry Bag                      (1) Bag of 24 S Hooks  
(3) 3' Mesh Panels **OR**  
(3) 4' Mesh Panels – for Oversize ZigZag frame



#### **Setup Instructions:**

1. Extend you four legs as per sidebar illustration. Slide a StaBar ell on each of two leg bottoms, and a StaBar 3 way on the other two leg bottoms (white arrows point down on all StaBar parts), then slide the foot plate onto the leg bottom. See picture.
2. Attach an indoor 3 way to the top of one of the leg assemblies that has a StaBar 3 way attached. Orient the 3 way so that the open (see through) barrel slides onto the leg.
3. With the leg lying down, attach a red-coded pole to each of the remaining barrels of the indoor 3 way. For ease of setup keep the leg units lying on the floor through the next few steps.
4. Attach an indoor ell (open barrel will slide onto the leg) onto the opposite end of one red coded pole, and an indoor 3 way to the opposite end of



the other red coded pole. Refer to the illustration on page 2 for proper orientation of the parts.



5. Attach a leg assembly with StaBar ell to the indoor ell, and a leg assembly with StaBar 3 way to the indoor 3 way.
6. Attach a red coded pole to each of the lower StaBar parts of the three leg assemblies. Now stand the assembled unit up.
7. Attach the remaining indoor ell to the top of the remaining leg assembly, and attach the leg to the rest of the frame using the remaining two red coded poles.
8. This completes the frame. Attach Mesh panels with the metal hooks at the top. Refer to the illustration.